LANDSCAPE GARDEN SPEAKER



Excellence in Audio Envirotainment®

Installation Instruction Sheet



Note: This installation instruction is good for all LGS models.











LGS100

LGS300

LGS400

Install Garden Speaker base to ground media using proper hardware.
(MOUNTING HARDWARE NOT INCLUDED)






3

Install Garden
Speaker upper
section onto
base. Connect
speaker wires
and test unit.
Insert mounting
screws supplied
with speaker into
pre-drilled holes
and tighten.




Check all wiring connections and your Landscape Garden Speaker is ready.



17141 Kingsview Avenue, Carson, CA 90746-1207 USA Tel: 310.515.1900 Fax: 310.515.1606

Web: www.owi-inc.com





OWI incorporated
Entertained 1978

17141 Kingsview Avenue, Carson, CA 90746-1207 USA
Tel: 310.515.1900 Fax: 310.515.1606
Web: www.owi-inc.com